

Wireless nRF24L01 adapter PCB



Socket Adapter plate Board for 8Pin NRF24L01 Wireless Transceiver module.

Wireless module operating voltage is generally 3.3v, while the ordinary microcontroller uses 5v, this module is easy to connect wireless module with system board used in conjunction.

This module is directly connected to the system board, easy to use.

It's for 8 Pin NRF24L01+ Module

This is a simple socket board which is for NRF24L01 Wireless module

On-board AMS1117-3.3 chip

It could be used with NRF24L01 Wireless module.